

Travelling boom irrigation systems

Calculating when to irrigate

Need to know:

- How much water is available in the soil? This requires an understanding of soil texture, decision on the maximum level of water stress to be applied to the crop and a measure of the crop rooting depth.
- How much water should the crop be using? This requires and understanding of type of crop, stage of crop growth, measure of climatic conditions including evaporation.

Step 1: Calculate the readily available water (RAW) in the crop root zone.

| Soil type (texture): | |
|------------------------------------|-----|
| Crop stress willing to be applied: | kPa |
| Crop rooting depth | |
| Month one: | m |
| Month two: | m |
| Month three: | m |
| Month four: | m |

Table 1: Effect of soil texture on RAW content

| Soil Texture | Readily Available Water (mm _{water} per m _{soil}) between field capacity and; | | | | | | | |
|--------------------------|--|---------|---------|----------|----------|--|--|--|
| Crop Stress Level | -20 kPa | -40 kPa | -60 kPa | -100 kPa | -200 kPa | | | |
| Sandy | 30 | 35 | 35 | 40 | 45 | | | |
| Loamy Sand | 45 | 50 | 55 | 60 | 65 | | | |
| Sandy Loam | 45 | 60 | 65 | 70 | 85 | | | |
| Loam | 45 | 65 | 75 | 85 | 105 | | | |
| Sandy Clay Loam | 40 | 60 | 70 | 80 | 100 | | | |
| Clay Loam | 30 | 55 | 65 | 80 | 105 | | | |
| Light Clay | 27 | 46 | 57 | 70 | 90 | | | |
| Medium Clay | 24 | 43 | 55 | 65 | 83 | | | |
| Heavy Clay | 21 | 40 | 53 | 60 | 81 | | | |

To calculate the RAW in the crop root zone

= RAW (in mm/m) x crop root depth (in m)

Month one: $mm/m \times m = mm$ of water Month two: $mm/m \times m = mm$ of water Month three: $mm/m \times m = mm$ of water Month four: $mm/m \times m = mm$ of water

Step 2: Calculate the expected crop water requirement.

Crop water requirement (mm/day) = crop coefficient x evaporation (mm/day)

- Select the appropriate crop coefficient for your crop from the monthly crop coefficients (Kc) factsheet. Remember that your growing season may differ to the growing seasons shown in this table.
- For each month of the crop growing season, select the appropriate daily evapotranspiration rates (mm/day) and add them to the following table.
- Crop coefficient x evapotranspiration (mm/day) = crop water requirement (mm/day)





| N. C | | e . t. | | | | | | | | | | |
|-------|-----|--------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Month | Jan | ьер | Mar | Apr | маy | Jun | Jui | Aug | Sep | Oct | Nov | рес |

Daily Evapotranspiration (mm/day)

Crop Coefficient (Kc)

Crop water requirement (mm/day)

· Convert the crop water requirement (expressed in mm/day) to a volumetric measure.

1 mm of water applied = 1 L/m²

100 mm of water applied = 1 ML/ha

Step 3: Use the data from steps 1 and 2 to work out the expected period between irrigations for each month

To calculate the period between irrigations

= RAW (in soil) ÷ crop water requirement (L/plant/day)

Month one: mm ÷ mm/day = days Month two: mm/day mm ÷ days Month three: mm ÷ mm/day Month four: mm ÷ mm/day days

Calculating how long to irrigate

You need to know:

- readily available water content of the area/volume wetted by the irrigation system
- water application rate or discharge from the travelling irrigator

Step 1: Calculate the readily available water (RAW) in the crop root zone.

Use the same steps as for Step 1 in the section calculating when to irrigate above.

Step 2: Measure the discharge from your irrigation application nozzle(s)

Discharge from one nozzle (L/hr) = volume in container (in Litres)

÷ time to fill container (in minutes) x 60 mins/hr

mins x 60 mins/hr

Discharge from one nozzle = L//hr To calculate the total discharge rate for the boom:

Total discharge (L/hr) = discharge from one nozzle x number of nozzles on boom

- L/hr x number of nozzles on boom
- L/hr

If you want to calculate the above application rate in mm/hr

Discharge (mm/hr) = discharge (L/hr) ÷ distance travelled in 1 hour ÷ wetted width

- L/hr ÷ m ÷ m
- mm/hr

Step 3: Use the data from steps 1 and 2 to calculate required speed of the traveller

To calculate the speed of travel (m/hr) required to apply the RAW for travelling boom systems.

= total discharge rate (L/hr) ÷ wetted width (m) ÷ RAW (mm)

mm

Month one: L/hr ÷ m/hr m mm Month two: L/hr ÷ mm m/hr m Month three: L/hr ÷ mm m/hr m m/hr Month four: L/hr ÷

m

For more details contact the Growcom members access line on 07 3620 3844.

Disclaimer: This information is provided as a reference tool only. Seek professional advice for irrigation specifics.

A Growcom project conducted in collaboration with the Department of Primary Industries and the National Centre for Engineering in Agriculture with funding provided by the Queensland Government's Rural Water Use Efficiency Initiative.





